# FELIX THE CAT<sup>™</sup> 3-D Motion Clock Assembly Instructions

#### (A) Battery installation

**Carefully** insert two AA batteries in the battery compartment, following the indicated polarity (+/-). Unlike most devices, batteries in this clock should **point in the SAME DIRECTION**. **Please do not use DURACELL® batteries**, which may be too large to

fit in the battery compartment and/or damage the contacts.

# (B) Adjusting the time

The **time set dial** is located just above the top battery, under the lip of the back of the clock (image at right is a "cutaway" view).

#### (C) Attaching the tail to the pendulum

The tail is tucked away in either the top or bottom compartment of the box. Insert it onto the pendulum as shown.

# (D) Starting the pendulum

After mounting the clock on the wall, ensuring that it hangs perfectly straight, push the tail gently to the left or right. It should swing continuously as the electromagnet pushes it along.

# Troubleshooting Tips:

#### Tail is missing

Try completely dismantling the box, checking in the top and bottom panels. If the tail is not there, please contact N.J. Croce Co.

#### Tail will not swing

- Is the clock hanging level to the wall so the tail can swing freely?
- Is the tail attached correctly and firmly to the pendulum?
- Is anything broken off or rattling around inside?
- See 'Battery Issues' (below)


#### Timepiece is not working


See 'Battery Issues' (below)

#### Battery issues:

- Are the batteies fully-charged, and installed at the correct polarity?
- If the batteries won't fit, try a different brand (see "A" above).
- Try spinning the batteries in the compartment for better contact.

FELIX THE CAT  $\ensuremath{^{\odot}}$  2018 DreamWorks Animation LLC. All Rights Reserved.





Revised 02/2018 Printed in China

# DO NOT RETURN THIS CLOCK TO THE STORE YOU BOUGHT IT FROM.

If your clock will not operate, after following the above instructions completely, please contact the manufacturer, N.J. Croce Company, for support: <u>800-899-8467 or 909-596-1800 (Mon</u>–Fri, 8am–4pm Pacific Time) | customerservice@njcroce.com